



# LISTA ÖVER KOMPATIBLA REGLAGE

Januari 2024

Saknas ditt reglage i listan? **FRÅGA OSS!**

Läs mer på [shipcontroller.se](http://shipcontroller.se)

---

### **MTU Blue Vision**

- Adapter type: Digital.
- Adapter p/n: EA-MTU/BV.
- Engine control: Single/Dual speed.
- Control head status monitoring: Yes.
- Control head activation from the remote: YES.
- Remote models: 100/756JY/756TG



---

### **MAN - REXROTH/AVENTICS (Canbus versions-5pin)**

- Adapter type: Digital.
- Adapter p/n: EA-MAN.
- Engine control: Single speed.
- Control head status monitoring: Yes.
- Control head activation from the remote: YES.
- Remote models: 100/756JY/756TG



---

### **SUZUKI Precision Control**

- Adapter type: Hybrid.
- Adapter p/n: EA-SZK.
- Engine control: Single/Dual Speed.
- Trim control from the remote: Soon.
- Remote models: 100/756JY/756TG



This space is intentionally blank.

---

### **VETUS EC3 / VETUS EC4**

- Adapter type: Digital.
- Adapter p/n: EA-VTS-EC4
- Engine control: Single/Dual speed /Proportional (1).
- Engine control activation from the remote: YES.
- Engine control monitoring: YES.
- Remote models: 100/756JY/756TG



---

### **VOLVO EDC / VOLVO EVC**

- Adapter type: Analog (Patented).
- Adapter p/n: EA-PATV5/VPANLG
- Engine control: Single/Dual speed.
- The remote can be used with the control levers in any position.
- Control head activation from the remote: optional.
- Control head status monitoring: optional.
- Remote models: 100/756JY/756TG



---

### **VOLVO EVC-E & EVC2.0**

- Adapter type: Volvo original Interface + Shipcontroller GTW
- Adapter p/n: EA-VPTJS
- Engine control: Single/Dual speed/Proportional (1).
- Engine control activation from the remote: YES.
- Engine control monitoring: YES.
- The EVC system must be upgraded to EVC-E4 o2 EVC2.0
- Remote models: 100/756JY/756TG



---

### **VOLVO IPS (JOYSTICK)**

- Adapter type: Digital
- Adapter p/n: EA-VPX8
- Engine speed control: Proportional control.
- The Joystick functions can be activated from the SC remote.
- Joystick status monitoring: YES.
- Remote models: 756JY-IPS
- In the case of EVC2.0, it is fully functional, but it triggers a system alert from EVC indicating that there is an unrecognized device.



---

### **WR CONTROLS, Flexball 4200 SERIES**

- Adapter type: Digital.
- Adapter p/n: EA-VTS
- Engine control: Single/Dual speed /Proportional (1).
- Control head status monitoring: Yes
- Control head activation from the remote: Yes.
- Remote models: 100/756JY/756TG



---

### **WR CONTROLS, Flexball 3500/4500 SERIES**

- Adapter type: Digital.
- Adapter p/n: EA-VTS
- Engine control: Single/Dual speed /Proportional (1).
- Control head status monitoring: Yes
- Control head activation from the remote: Yes.
- Remote models: 100/756JY/756TG



---

### **Yanmar VC10/Yanmar VC20**

- Adapter type: Analog + Yanmar Original interface.
- Adapter p/n: EA-YNMR-VC10/VC20
- Engine control: Single/Dual speed.
- Control head status monitoring: Yes
- Control head activation from the remote: Yes.
- Remote models: 100/756JY/756TG



---

### **ZF Smartcommand**

- Adapter type: Digital.
- Adapter p/n: EA-ZFSMC
- Engine control: Single/Dual speed /Proportional (1).
- Control head status monitoring: Yes
- Control head activation from the remote: Yes.
- Remote models: 100/756JY/756TG



---

### **ZF –Microcommander, ClearCommand, CruiseCommand, MS series.**

- Adapter type: Hybrid.
- Adapter p/n: EA-ZFMCC/ZFCCM
- Engine control: Single/Dual speed
- Control head activation from the remote: yes.
- Control head status monitoring: Yes.
- Remote models: 100/756JY/756TG



## PROPORTIONAL THRUSTERS COMPATIBILITY LIST

- SLEIPNER PROPORTIONAL THRUSTERS
  - Control interface:
    - Sleipner GW-1 + Shipcontroller IFTH-SLINK
  - Thruster models supported:
    - ALL S-LINK proportional thrusters (AC, DC, Hydraulic).
  - Control features:
    - Thrusters activation
    - Proportional control 0% to 100%
  - Remotes support:
    - SCR100: fixed thrust control.
    - SCR756TG: variable, user adjustable thrust.
    - SCR756JY: variable, user adjustable, proportional.
  
- VETUS PROPORTIONAL THRUSTERS
  - Control interface:
    - Shipcontroller IFTH-VCAN
  - Thruster models supported:
    - ALL VCAN proportional thrusters (AC, DC, Hydraulic).
  - Control features:
    - Thrusters activation
    - Proportional control 0% to 100%
  - Remotes support:
    - SCR100: fixed thrust control.
    - SCR756TG: variable, user adjustable thrust.
    - SCR756JY: variable, user adjustable, proportional.